

Manual, Assembly instruction: Brodit 854207

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the picture before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the upper and lower part of the control panel.
2. Flip the ProClip upward/forward so the angled lower edge hooks behind the lower part of the control panel. Hook the angled edge on the upper part of the ProClip over the lower edge of the air vent.
3. Press down on top of the ProClip so the adhesive tape attaches.
4. The ProClip is in place.