

Manual, Assembly instruction: Brodit 854208

Angled mount ONLY for DIN stereo.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the stereo and the center console to widen the gap.
2. Press the curved edge on the left part of the ProClip into the gap between the stereo and the surrounding frame. Flip the ProClip rightward/forward so the curved left edge hooks behind the stereo.
3. Press down on the right side of the ProClip so the angled edge hooks into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.