

Manual, Assembly instruction: Brodit 854210

Angled mount, Low ONLY for manual gear shift.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the center console, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

3. Press downward on the right side of the ProClip so the angled edge hooks into the center console sidewall. Press until you hear/feel it snaps into place. Press until you hear/feel it snaps into place.

4. The ProClip is in place.