

## Manual, Assembly instruction: Brodit 854216

Angled mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the left part of the ProClip into the gap below the gap opener.
3. Press forward on the right side of the ProClip so the angled edge hooks around the center console frame. Press leftward on the right part until you hear/feel the edge snaps into place. Pull out the gap opener.
4. The ProClip is in place.