

Manual, Assembly instruction: Brodit 854219

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the stereo and the console, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the grooved edge on the ProClip into the gap below the gap opener.

2. Press forward on the upper part of the ProClip so the grooved edge goes all the way into the gap.

3. Press forward on the lower part of the ProClip so the grooved edge goes all the way into the gap and the adhesive tape attaches. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.