

Manual, Assembly instruction: Brodit 854222

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Pull the upper part of the ProClip forward and hook the angled edge into the gap between the dashboard and the panel surrounding the information window.
3. Pull down on top of the ProClip so the angled upper edge goes all the way into the gap.
4. The ProClip is in place.