

Manual, Assembly instruction: Brodit 854223

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Place the ProClip onto the frame surrounding the control panel.
3. Press the angled edge on the left part of the ProClip into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.