

Manual, Assembly instruction: Brodit 854233

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap in the console sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Place the ProClip over the console edge. Press the angled edge on the right side of the ProClip into the gap above the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

3. Hold your hand around the face plate and push it sideways, towards the stereo. Then press firmly forward on the left side of the ProClip so the angled edge goes into the gap between the stereo and the console edge.

4. The ProClip is in place.