

Manual, Assembly instruction: Brodit 854246

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment door. Press the thin end of the enclosed gap opener into the gap between the stereo and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip (behind the face plate) into the gap above the gap opener. Pull out the gap opener.
3. Press firmly forward on the right side of the ProClip so the angled edge goes into the seam/gap in the sidewall. Press until you see or hear/feel it click into place. Close the glove compartment.
4. The ProClip is in place.