

Manual, Assembly instruction: Brodit 854248

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent and the surrounding panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the air vent and the surrounding panel frame. Press the angled edge on the lower part of the ProClip upwards and then hook it into the gap next to the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.