

Manual, Assembly instruction: Brodit 854250

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the padded part of the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the gap opener into the gap between the air vent and the padded dashboard. Hold the gap opener in this position and press down on top of the ProClip so the angled edge goes into the gap next to the gap opener. Press down on the right side first and then on the left side so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.