

Manual, Assembly instruction: Brodit 854252

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the upper and the lower section of the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Flip the ProClip downward so the curved upper edge hooks behind the frame surrounding the air vent.

3. Pull the lower part of the ProClip downward and hook the edge into the gap next to the gap opener. Press forward on the lower part of the ProClip so the edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.