

Manual, Assembly instruction: Brodit 854254

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Hold one of the enclosed gap openers in an almost 45 degree angle and press the thin end into the seam in the sidewall, to widen gap. Press the second gap opener into the gap approx. 55 mm/2.5 inches below the first gap opener.

2. Pull out the first gap opener and press it into the gap between the center console panel and the console edge, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap above the gap opener.

3. Press firmly forward on the right side of the ProClip so the ProClip flexes forwards and the angled edge goes into the gap above the gap opener. Press until you see or hear/feel it clips into place. Pull out the gap openers.

4. The ProClip is in place.