

Manual, Assembly instruction: Brodit 854257

Angled mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the curved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the control panel.
2. Flip the upper part of the ProClip upward/forward so the curved edge hooks behind the control panel.
3. Press the upper part of the ProClip downward and then forward. Release the pressure when the grooved upper edge is in the air vent so it hooks into the upper edge of the air vent.
4. The ProClip is in place.