

Manual, Assembly instruction: Brodit 854259

Center mount, High NOT for models with factory navigation.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE: This ProClip can not be combined with item no 854256, both of them can not be installed in the same time in one vehicle.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the display and the frame surrounding the center console. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener and press it all the way into the gap. Pull out the gap opener.

2. Pull the ProClip downward and then press it ward so the grooved edge hooks into the upper part of the air vent.

3. The ProClip mount is in place.

4. The ProClip mount is in place.