

Manual, Assembly instruction: Brodit 854260

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Clean the area where the ProClip will be installed with the enclosed alcohol pad. Peel off the adhesive tape covers on the ProClip. Place the upper edge of the ProClip under the upper edge of the air vent.

2. Press the lower part of the ProClip upward and forward. Hook the angled edge in the lower part over the lower edge of the air vent.

3. Press the lower part of the ProClip downward so the adhesive tape attaches.

4. The ProClip is in place.