

Manual, Assembly instruction: Brodit 854261

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Fits models with regular stereo and full screen stereo & navigation.

1.Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding panel frame, to widen the gap. Press the curved edge on the left part of the ProClip into the gap below the gap opener.

2. Flip the ProClip to the right so the curved left edge hooks behind the stereo panel, and the right angled edge meets the padded part for the dashboard. Then place your left index finger behind the right side of the ProClip and bend out at the same time as you push forward on the right side of the ProClip. Push until you see or hear/feel the angled edge goes into the seam/gap in the dashboard sidewall.

3.Press firmly on the right upper side to make sure the angled edge goes all the way into the gap. You should hear a click when it goes all the way in. Pull out the gap opener.

4. The ProClip is in place.