

Manual, Assembly instruction: Brodit 854264

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts. Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Place the thin edge of Part 1 against the gap between the gap openers.

2. Press the thin edge firmly into the gap and at the same time: bend Part 1 to the right until you see or hear/feel it click into place. Pull out the gap openers.

3. Press a screwdriver (Philips) firmly through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape on Part 2 is on the left side. Do not press the tape to the center console panel frame yet. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip to the right with your thumb for optimal adjustment of the mount. Then press the adhesive tape on the left side of Part 2 to the center panel. Hold the ProClip in that position and tighten the screws.

4. The ProClip is in place.