

Manual, Assembly instruction: Brodit 854271

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the stereo and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip/Press the ProClip forward so the curved lower edge hooks behind the frame surrounding the stereo. Pull out the gap opener. Press the gap opener into the gap between the upper and the lower section of the dashboard.

3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.