

Manual, Assembly instruction: Brodit 854277

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the grooved edge on the left part of the ProClip into the gap between the control panel and the surrounding frame.
2. Slide the ProClip upward in the gap until it stops.
3. Press forward on the right side of the ProClip so the grooved edge goes into the gap between the dashboard and the trim. Press until you hear/feel it snaps into place.
4. The ProClip is in place.