

Manual, Assembly instruction: Brodit 854280

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the center console and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener.

2. Pull the ProClip toward you and hook the angled edge on the lower part under the upper edge of the air vent.

3. Press on the ProClip so the adhesive tape attaches. Pull out the gap opener.

4. The ProClip is in place.