

Manual, Assembly instruction: Brodit 854281

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

3. Press the gap opener into the gap in the center console side wall. Press forward on the right side of the ProClip so the angled edge hooks into the gap below the gap opener. Press the angled edge all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.