

Manual, Assembly instruction: Brodit 854283

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the control panel and the dashboard.

2. Flip the ProClip upward/forward so the angled lower edge hooks behind the frame surrounding the control panel.

3. Hook the angled edge on the upper part of the ProClip into the gap between the gap openers. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.