

Manual, Assembly instruction: Brodit 854285

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Press forward on the lower part of the ProClip until you hear/feel the grooved edge snaps into place.
3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.