

Manual, Assembly instruction: Brodit 854293

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. The instructions show how to install the ProClip by the left air vent. The ProClip can also be installed by the right air vent by turning it up side down and following the same installation procedure.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.
2. Press the angled edge in the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Hook the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Press down on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.