

Manual, Assembly instruction: Brodit 854294

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the left part of the ProClip into the gap below the gap opener. Pull out the gap opener.

2. Press the gap opener into the lower corner of the gap in the center console sidewall.

3. Slide the gap opener upward into the gap so it widens the gap below the ProClip. Press the angled edge on the right part of the ProClip all the way into the gap above the gap opener. Pull out the gap opener.

4. The ProClip is in place.