

Manual, Assembly instruction: Brodit 854296

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the right part of the ProClip in the closest gap in the back side of the center console.

2. Press the angled edge all the way into the gap.

3. Pull the ProClip toward you so it flexes and hook the left edge over the frame surrounding the center console. Press forward on the left part of the ProClip so the adhesive tapes attach.

4. The ProClip is in place.