

Manual, Assembly instruction: Brodit 854301

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard edge and the top part of the center console ledge, placed centered on the console, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Keep holding the ProClip in an angled direction so the tape doesn't attach. Pull out the gap opener.

2. Press the gap opener into the gap between the dashboard edge and the top part of the center console ledge, placed above the gap in the console. Slide the ProClip leftwards all the way over to the gap opener. Note: If you have a factory navigation system, you cannot slide the mount all the way over. Stop approx 1 inch/2,5 cm from the left corner. Pull out the gap opener.

3. Place your index fingers behind the ProClip face plate and pull it towards you. The ProClip will now flex towards you. Hook the angled edge on the lower part of the ProClip into the gap between the stereo and the surrounding panel frame. Press firmly forward on the lower part of the ProClip to make sure the angled edge is all the way into the gap.

4. The ProClip is in place.