

Manual, Assembly instruction: Brodit 854302

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the panel frame surrounding the air vent, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Hook the curved edge on the right side of the ProClip around the center console sidewall edge.
3. Place your hand over the ProClip face plate and push it to the left. The ProClip will now flex towards the stereo. Then press forward on the left side of the ProClip so the angled edge goes into the gap below the gap opener. Pull out the gap opener.
4. The ProClip is in place.