

Manual, Assembly instruction: Brodit 854307

Center mount ONLY for models with silver or wood grain trim.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip is divided into two parts. Part 1: The attaching part (the smallest part) Part 2: The ProClip faceplate

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the air vent panel frame and the dashboard edge, to widen the gap. Peel off the cover of the adhesive tape on Part 1.

2. Place the thin edge of Part 1 against the gap next the gap opener. Press the thin edge firmly into the gap and at the same time: bend Part 1 upwards until you see or hear/feel it click into place. Pull out the gap opener.

3. Press a screwdriver (Philips) through the predrilled holes in Part 2 to open them up. Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match. Do not press the tape to the air vent panel frame yet. Screw Part 2 onto Part 1 using the enclosed screws. Right before you tighten the screws press the ProClip upwards with your thumb for optimal adjustment of the mount. Press the adhesive tape on the lower part of Part 2 to the air vent panel. Hold the ProClip in that position and tighten the screws.

4. The ProClip is in place.