

Manual, Assembly instruction: Brodit 854308

Angled mount ONLY for floor gear shift.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook/press the angled edge on the right side of the ProClip into the gap in the center console sidewall.

2. Place your hand on the right side of the ProClip and push firmly to the left, towards center console panel. The ProClip will now flex leftward. Push until the angled edge on the left side of the ProClip hooks/snaps around the center console edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.