

Manual, Assembly instruction: Brodit 854319

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the thin edge with tape on the upper part of the ProClip into the air vent towards the upper air vent overhang.
2. Place your thumbs on the lower part of the ProClip and push firmly upwards so the bottom part with tape attaches to the air vent ledge.
3. Press down on the inside of the ProClip for best possible attachment of the adhesive tape.
4. The ProClip is in place.