

Manual, Assembly instruction: Brodit 854322

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. The ProClip fits models with and without factory navigation screen.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard ledge and the center console top, to widen the gap. Peel off the cover of adhesive tape on the ProClip. Hook the curved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it click into place. Pull out the gap opener.

2. Place your fingers behind the ProClip face plate and pull towards you. The ProClip will now flex forward. Then hook the angled edge around the upper air vent edge.

3. The ProClip can be attached anywhere within the width of the air vent and you can have two ProClips attached next to each other. This instruction applies for either position.

4. The ProClip is in place.