

Manual, Assembly instruction: Brodit 854324

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the thin edge with adhesive tape onto the upper inner part of the air vent.
2. Press firmly upwards on the lower part of the ProClip. It will now flex upwards. Then insert the thin edge with adhesive tape onto the lower inner part of the air vent.
3. Place your finger on the upper inside of the ProClip and press firmly upwards for best possible attachment of the adhesive tape.
4. The ProClip is in place.