

Manual, Assembly instruction: Brodit 854326

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the lower part of the ProClip into the gap/seem between the air vent and the air vent edge.
2. Press down on the upper part of the ProClip and hook the angled edge into the gap/seem between the air vent and the air vent edge.
3. Press upwards to make sure the upper angled edge is all the way into the gap.
4. The ProClip is in place.