

Manual, Assembly instruction: Brodit 854327

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in an almost horizontal position. Press the curved edge on the right side of the ProClip into the seam in the sidewall at the same position as shown in picture. (Note, It will not fit if you slide it too far down or up in the seam)

2. Press the thin end of the enclosed gap opener into the gap between the center console panel edge and the console edge, to widen the gap. Place your index fingers behind the ProClip. Pull the ProClip so it flexes towards you and hook the angled edge around the center console edge and into the gap below the gap opener. Pull out the gap opener.

3. The ProClip mount is in place.

4. The ProClip mount is in place.