

Manual, Assembly instruction: Brodit 854329

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.
2. Press the grooved edge on the upper part of the ProClip into the gap between the frame surrounding the air vent and the dashboard overhang. Press until you hear feel it snaps into the place.
3. Press forward on the center of the ProClip so the grooved vertical edge goes into the gap between the gap openers. Press until you hear feel it snaps into the place. Pull out the gap openers.
4. The ProClip is in place.