

Manual, Assembly instruction: Brodit 854331

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the center console frame, to widen the gap. Open the glove compartment.

2. Press the angled edge on the right part of the ProClip into the gap between the glove compartment and the dashboard. Flip the ProClip leftwards so the angled right edge hooks behind the glove compartment.

3. Press the grooved edge on the left part of the ProClip into the gap above the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener. Close the glove compartment.

4. The ProClip is in place.