

Manual, Assembly instruction: Brodit 854336

Angled mount NOT for models with glove compartment.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the upper part of the ProClip over the edge of the compartment.
2. Press the ProClip downward and hook the angled edge on the lower part under the edge of the console.
3. Press the lower part of the ProClip upward so the angled edge hooks into place properly and the adhesive tapes attach.
4. The ProClip is in place.