

Manual, Assembly instruction: Brodit 854338

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the upper and lower section of the dashboard. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the panel and the dashboard overhang.

2. Pull the ProClip upward and press the grooved edge on the upper part into the gap next to the gap opener.

3. Press forward on the upper part of the ProClip until you hear/feel it snaps into place in the gap. Pull out the gap opener.

4. The ProClip is in place.