

Manual, Assembly instruction: Brodit 854342

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the center console sidewall to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the left part of the ProClip into the gap between the stereo and the surrounding frame.

3. Press the right part of the ProClip forward so the angled edge hooks into the gap above the gap opener. Press the right part of the ProClip toward the center console so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.