

Manual, Assembly instruction: Brodit 854344

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard and the frame surrounding the air vent, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. In the same time: Press the upper part of the ProClip forward so the angled edge goes into the gap. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.