

Manual, Assembly instruction: Brodit 854347

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the coin compartment and the frame surrounding the air vent. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the the frame surrounding the control panel and the frame surrounding the air vent. Press the ProClip downward and hook the angled lower edge into the gap next to the gap opener. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap.

3. Pull out the gap opener. Close the coin compartment.

4. The ProClip is in place.