

Manual, Assembly instruction: Brodit 854352

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the stereo and the frame surrounding the air vent. Pull the ProClip toward you and hook the angled lower edge into the gap next to the gap opener.

3. Press the angled lower edge all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.