

Manual, Assembly instruction: Brodit 854354

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip fits over either air vent, you can also have two ProClips attached next to each other. This installation instruction applies for both placements.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the angled edge of the enclosed gap opener upward into the gap between the upper part of the air vent and the padded dashboard overhang, to widen the gap. It is important to locate the gap and it will help to gently raise or lift the front edge of the padded part on the dash slightly with your hand to determine or see where the gap is. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.

3. Hold the ProClip into the upper gap. Then with your other hand slowly push the lower part of the ProClip forward until the angled lower edge clicks into the seam/gap between the air vent and the surrounding frame. Pull out the gap opener.

4. The ProClip is in place