

Manual, Assembly instruction: Brodit 854360

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip fits models with and without factory navigation screen.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Close the air vent while attaching the ProClip. (When the ProClip is attached the air vent can opened and adjusted freely.) Peel off the cover of adhesive tape on the ProClip.

2. Hook/Place the angled edge on the lower part of the ProClip around the edge of the wood grain trim.

3. Place your index fingers underneath the top part of the ProClip. Then push upwards and hook the angled edge around the air vent edge (into the seam between the air vent and the surrounding panel frame). Adjust the air vent to desired position.

4. The ProClip is in place.