

Manual, Assembly instruction: Brodit 854362

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip fits models with and without factory navigation screen, and can be attached below either air vent as shown in the picture. You can also have to ProClip attached at the same time.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Close the air vent while attaching the ProClip. (When the ProClip is attached the air vent can be opened and adjusted freely). Peel off the cover of adhesive tape on the ProClip. Press/hook the angled edge on the lower part of the ProClip into the gap between the center console panel frame and the dashboard overhang.

2. Press firmly forward on top of the ProClip so the angled edge hooks around the air vent edge.

3. The ProClip mount is in place.

4. The ProClip mount is in place.