

Manual, Assembly instruction: Brodit 854374

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed Gap Opener (Spaltöffner)s into the gap between the stereo and the surrounding panel frame, to widen it. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the right side of the ProClip into the seam between the air vent wall and the surrounding panel frame.
2. Press the angled edge on the right side of the ProClip into the seam between the air vent wall and the surrounding panel frame.
3. Press firmly forward on the left side of the ProClip so the thin edge goes into the gap between the Gap Opener (Spaltöffner)s. Pull out the Gap Opener (Spaltöffner)s.
4. The ProClip is in place.