

Manual, Assembly instruction: Brodit 854376

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the seam/gap between the air vent and the surrounding panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press down on top of the ProClip and hook/press the angled edge into the seam/gap between the air vent and the surrounding panel frame .
4. The ProClip is in place.