

## Manual, Assembly instruction: Brodit 854379

Center mount NOT for models with USB port.

1.)



2.)



3.)



4.)



**Please read all the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the panel surrounding the air vents and the center panel, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip downward so the upper curved edge hooks behind the panel surrounding the air vents. Pull out the gap opener.

3. Press the gap opener into the gap between the center panel and the console. Hook the angled edge on the lower part of the ProClip into the gap next to the gap opener. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.